

FLOOR CARE



AACER[™]
SPORTS FLOORING

Caution!

NEVER

Shut down the ventilation system in your facility for a *prolonged period of time*.

NEVER

Clean your Acer wood floor using scrubbing machinery or power scrubbers that use water under pressure. Water is your floor's worst enemy!

NEVER

Lag bleachers, equipment, or fixtures through wood floors into concrete without first cutting wood away from lag bases and making provisions for expansion in floating type floor systems.

NEVER

Modify or repair your Acer sports floor without first consulting with your flooring contractor.

PLEASE POST IN OFFICE OF SUPERINTENDENT, MAINTENANCE ENGINEER OR CUSTODIAN.

If you have any questions or require additional information please contact Acer customer service.

AcerFlooring.com
(877) 582-1181

GENERAL CARE

HUMIDITY AND VENTILATION

Humidity and ventilation are critical considerations for your new wood floor. 35-50% relative humidity is normally required for a long trouble-free life. If humidity rises to over 50%, opening interior doors and windows and activating the ventilating systems should initiate prompt air circulation. However, do not draw warm, moist air in from outdoors, as excessive humidity will cause wood to expand. Summer months are especially critical. Inspect your wood floors regularly. If necessary, turn on the heating system. If less than 35% humidity level persists, use humidification to prevent excessive dryness and possible wood shrinkage. In areas of high or low outside humidity, a 15% fluctuation is generally acceptable for your maple floor.

Excessive Tightening

When excessive tightening of the floor becomes noticeable, call your flooring contractor or manufacturer (877-582-1181) IMMEDIATELY.

Joint Separation

When unusually wide cracks begin to appear, call your flooring contractor or manufacturer (877-582-1181) IMMEDIATELY.

Control Air Conditioning & Humidity

Be sure that your air conditioning system is operating at a consistent temperature and within the 35-50% range of normal relative humidity. Ventilation equipment should be available for year-round use.

Exercise Care to Prevent Exposure to Moisture

Any evidence of dampness within your building should be called to the attention of your architects and engineers. Interior drains and downspouts should be properly insulated to prevent development of excessive condensation and moisture.

Expansion Joints

Expansion joints around the perimeter of your floor, at columns, or inserts, should never be blocked or obstructed. They have been engineered into your floor to permit natural expansion and contraction from the normal humidity changes without damage to your floor. Clip and Channel Floor Systems are designed to contain expansion within the system. No perimeter expansion voids are necessary. Anchoring of the bleachers and equipment through the floor without expansion is permitted. This applies to clip and channel floor systems only. ANY nailed floor will expand and move. ALL nailed floors require 1.5" – 2" perimeter expansion voids.

Anchoring Bleachers

No fixtures, equipment or bleachers should be lagged through wood floors into concrete without first cutting wood away from lag bases and making provisions for expansion in floating type floor systems.

Steel Channel Floor Systems

Steel Channel Floor Systems are designed to contain expansion within the system. No perimeter expansion voids are necessary. Anchoring of the bleachers and equipment through the floor without expansion is permitted. This applies to steel channel floor systems only.

DAILY CARE

Approved Cleaning Products

Aacer has developed specific cleaning products for the care of your wood sports floor.:

- Aacer CourtKleen™ Daily – an ideal daily cleaning solution for your Aacer sports floor
- Aacer CourtKleen™ Intensive – use once a month for a deep, thorough cleaning of your court floor

To purchase these recommended cleaning products call 1-877-582-1181 or visit www.aacerflooring.com

Daily Sweeping

Daily sweeping with a properly treated dust mop will keep the floor surface free of dust, grit, sand and abrasive particles. A heavily used floor may require sweeping several times daily.

Floor Stains

Floor stains can be avoided by wiping spillage from the surface immediately. Staining occurs when spills are absorbed into the finish.

Remove Marks

Remove marks with a floor cleaner approved for use on wood floors. Apply with a soft cloth or dust mop and follow label directions. Do not use a lamb's wool applicator

Avoid Water on your Wood Floor Surface

Take precautions during inclement weather to prevent tracking of water on the floor. Also check that windows and doors do not admit water. Machine scrubbing or power machines that use water should not be used.

PRECAUTION: WATER SHOULD NEVER BE USED ON A FLOOR FOR CLEANING PURPOSES.

Refinishing the Floor

Consult your flooring contractor when it is time to refinish the floor. This person is experienced and is best qualified to do the job.

If you have any questions or require additional information please contact Acer customer service at 877.582.1181

PLEASE POST IN OFFICE OF SUPERINTENDENT, MAINTENANCE ENGINEER OR CUSTODIAN.