



Care & Maintenance

MP Elite™



1. Keep the surface of the MP Elite System clean. Dust mop daily to remove dirt and grit.
2. Use of a scrubber is permissible for daily cleaning, however, use soft brushes or a red buffing pad. Do not use stripping pads (green, brown or black).
3. Use only low-Ph, non-phosphorous, neutral cleaners to clean the floor. Do not use harsh detergents, caustic chemicals, abrasive cleaners or chlorine bleach. *MP Cleaner by Aacer Flooring* is available directly from Aacer Flooring or your local representative.
4. Walk-off mats should be used at doorways to clean abrasive grit from players' shoes.
5. Players should wear shoes with non-marking soles.
6. No spikes are allowed.
7. Protect all metal table and chair legs. Do not drag sharp metal objects across the floor.
8. Call your local Aacer representative for repairs, resurfacing or specific questions on daily floor care.
9. Aacer recommends walk off mats at heavy street traffic entryways to catch major contaminants.